

# **INSTALLATION INSTRUCTIONS**

Accessory

XM RADIO SYSTEM (EX)

Application

**2006 PILOT** 

Publications No.

All 30524-31586


Issue Date **DEC 2005** 


NOTE: Will not work with CD changer Attachment Kit

## **PARTS LIST**


XM Radio Attachment (sold separately) P/N 08B15-S9V-101

2 Tuner bracket





**BUS** cable



3 Cushion tapes




**EPT** sealer




Doublefaced tape



17 Wire ties



Wire tie with clip



4 Flange bolts, 6 x 12 mm



5 Pan screws, 5 x 8 mm



5 Plain washers, 5 mm




Pillar clip




XM Antenna (sold separately) P/N 08A15-EX5-100

Antenna



Splitter




Connector clip



## XM Unit (sold separately) P/N 08A15-EX5-000

XM tuner



## **TOOL AND SUPPLIES REQUIRED**

#2 Phillips screwdriver

Flat-tip screwdriver

Utility knife

Diagonal cutters

Tape measure

Shop towel

Scissors

Ratchet

10 mm and 14 mm Socket

10 mm and 14 mm Combination wrenches


Felt-tip pen

Isopropyl alcohol

(Isopropyl alcohol, in a 60/40 solution with water)

25 w TORX


## Illustration of the XM radio Installed on the Vehicle



#### **INSTALLATION**


Customer Information: The information in this installation instruction is intended for use only by skilled technicians who have the proper tools, equipment, and training to correctly and safely add equipment to your vehicle. These procedures should not be attempted by "do-it-yourselfers."

- 1. Make sure you have the anti-theft code for the radio, then write down the frequencies for the preset buttons.
- 2. Disconnect the negative cable from the battery.
- Remove the cap from the right sun visor (four retaining tabs).




4. Remove the right sunvisor (two Torx screws and unplug the connector).


5. Remove two caps from the right front grab rail and remove the grab rail (two screws).




 Pull away the door weatherstrip from around the right front piller trim. Using a small rubber mallet, and a shop towel, gently tap the right quarter pillar trim at the area marked "SIDE CURTAIN AIRBAG" to release the clip.




7. Remove the door weatherstrip from the opening edge of the right front door in the area shown, then remove the right front pillar trim (one clip).




8. Lower the glove box by removing the right and left stops.




9. Remove the meter panel (two self-tapping screws and two clips).




10. Remove the meter sub panel (three clips).



11. Gently pull out on the left side of the audio panel to release the two clips, then pull out to release the remaining three clips. Unplug the vehicle connectors and remove the audio panel.




12. Remove the audio unit (four screws, pull the audio unit out toward you, unplug the vehicle connectors and vehicle antenna connector).




## Vehicle with player


 Remove the driver's and passenger's center console trim pieces (three clips each). Take care not to damage the clips.




 Remove four self-tapping screws that fasten the center panel.




 Pull the center panel out toward you to release the two clips. Unplug the vehicle connector from the accessory socket, and remove the center panel.  Remove four screws that fasten the left and right vehicle brackets. Pull the heater control unit and pocket out toward you, and unplug the vehicle connectors.




13. Remove the driver's center console lower cover (seven clips). Take care not to damage the clips.




14. Remove the driver's seat front cover from the driver's seat (four clips).




15. Remove the driver's seat rear cover from the driver's seat. Take care not to damage the clips.




16. Remove the four bolts that secure the driver's seat side rails to the floor.




17. Using isopropyl alcohol, clean the windshield where the antenna will attach. Remove the adhesive backings from the antenna and attach the antenna to the front window at the location shown. Install the antenna by applying sufficient pressure.




18. Route the antenna harness along the right front pillar and through the right front pillar trim opening. Secure the antenna harness to the vehicle harness with five wire ties.




 Route the antenna harness through the glove box opening and route it along the vehicle harness.
Secure the antenna harness to the vehicle harness with four wire ties.




 Route the antenna harness to the audio unit opening and secure it to the vehicle harness with one wire tie.




21. Continue routing the antenna harness and one end of the BUS cable through the radio opening and down along the vehicle harness. Align the other end of the BUS cable with the vehicle 20-pin connector. Then secure the antenna harness and BUS cable to the vehicle harness with one wire



22. Route the antenna harness and BUS cable along the vehicle harness toward the floor, of the lower center console, and them out from under the driver's center console lower cover as shown.




23. Secure the antenna harness and BUS cable to the vehicle harness and to the vehicle frame with two wire ties in the areas shown.




# Vehicle with player


 Bundle the BUS cable with a wire tie as shown.



- Route the antenna harness along the vehicle frame as shown.
- Pull the BUS cable by the length shown from the vehicle wire tie of the heater control unit opening.
- Secure the BUS cable to the vehicle harness using a wire tie.




 Secure the antenna harness and BUS cable to the vehicle frame with three ties in the areas shown.




Connect the bus cable 14-pin connector to the player.


## Cassette player




## MP3 player




Remove the two washer-screws from the dashboard.




24. Plug the BUS cable 14-pin connector, vehicle connectors and vehicle antenna connector into the audio unit, then carefully slide the audio unit into the audio unit opening.




25. Reinstall the audio unit with four screws (you removed).




26. Clean with alchol pad. Cut a cushion tape in half. Attach the two halves of the cushion tape to the vehicle frame at the locations shown.




27. Measure and slit the driver's floor carpet area shown. Route the antenna harness and BUS cable under the floor carpet and out the slit. Take care not damage to the antenna harness and BUS cable when cutting the floor mat.



28. Attach the tuner brackets to the XM tuner with four 5 x 8 mm pan screws and four 5 mm plain washers.




29. Using isopropyl alcohol, clean the area where the doublefaced tape will attach. Remove the adhesive backing from the doublefaced tape and attach it to the splitter.




- 30. Remove the adhesive backing from the other end of the doublefaced tape and install the splitter to the XM tuner with one 5 x 8 mm pan screw and one 5 mm plain washer.
- 31. Install the connector clip to the splitter 1-pin connector.


32. Plug the splitter 2-pin connector into the XM tuner.




- 33. Using isopropyl alcohol, clean the area where the cushion tape will attach. Secure the splitter 2-pin connector cable to the XM tuner with one cushion tape.
- 34. Install the tuner bracket to the driver's seat rails with the four 6 x 12 mm flange bolts. Tighten the bolts securely.



35. Plug the BUS cable 14-pin connector into the XM tuner 14-pin connector.




- 36. Connect the antenna connector to the splitter 1-pin connector.
- 37. Secure the BUS cable to the tuner bracket with one wire tie with clip as shown.




38. Install the connector clip from the splitter 1-pin connector to the tuner bracket .

39. Bundle the excess of the antenna harness. Secure the antenna harness to the vehicle's harness using two wire ties.



40. Bundle the excess of the BUS cable. Secure the BUS cable and the antenna harness to the vehicle's harness.

- 41. Check that all wire harnesses are routed properly and all connectors are plugged in.
- 42. Reinstall the driver's seat. Take care not to pinch the any wires. Torque the seat bolts to 47 N·m (35 lbf·ft).
- 43. Remove the clip from the top of the right front pillar trim, and install a new pillar clip.



- 44. To install the pillar clip, position it at right angles to the right front pillar and install by lightly pushing on the area marked with "SIDE CURTAIN AIRBAG" on the right front pillar trim. Check that the pillar clip is not interfering with the airbag. Take care not to push the right front pillar trim excessively.
- 45. Reinstall all removed parts.
- 46. Reconnect the negative cable to the battery.
- 47. Enter the customer's radio anti-theft code, and reset the radio station presets.
- 48. Reset the clock.

NOTE: Whenever the battery is disconnected, the driver's AUTO function is disabled.

- 49. Start the engine. Push down on the driver's window switch until the window is fully open.
- 50. Pull up on the driver's window switch to close the window completely, then hold the switch for a second or 2 more.
- 51. Test the AUTO window function.