# HONDA INSTALLATION INSTRUCTIONS

Accessory

ALL-SEASON FLOOR MATS P/N 08P13-T0A-110 Application

2013 CR-V


Publications No.
All 13128

Issue Date
AUG 2012


Put this information in the glove box with the vehicle owner's manual.

## **PARTS LIST**


Driver's all-season floor mat




Passenger's all-season floor mat



Rear all-season floor mat




# Illustration of the All-Season Floor Mats in the Vehicle




### INSTALLATION

### NOTE:

- Remove the standard floor mats before installing the all-season floor mats.
- An anchor is required for the driver's side of the vehicle; the anchor prevents the mat from sliding forward and possibly interfering with the pedals.
- If you remove the all-season floor mat, make sure you reanchor it when you put it back in your vehicle.
- If you replace the all-season floor mat, use factory allseason floor mat designed to be used with the anchor.
- If you use a non-factory mat in the driver's foot well, make sure it fits properly and that it can be used with the anchor.
- Do not put additional mats on top of the anchored mat, otherwise the additional mats may slide forward and possibly interfere with the pedals.
- Identify each mat by the marks on the back of each mat: the mat marked "R" or "Passenger's side" go on the right side of the vehicle; the mat marked "L" or "Driver's side" go on the left side.
- Install the rings in the driver's all-season floor mat over the anchors. Turn the knob on each anchor 90° to secure the driver's all-season floor mat.



2. Position the passenger's all-season floor mat as shown. If equipped with a subwoofer, insert the rear portion of the passenger's all-season floor mat under a subwoofer.



3. Position the rear all-season floor mat as shown.

